

Windows Quick Keys - v5.12

BASICS	Undo		WINDOW	Default	
	Redo			Auto (Type 1)	
	Delete Selected			Auto (Type 2)	
	Copy Selected			Auto (Type 3)	
	Copy All			Auto (Min Max)	
	Paste				
	Hide All				
	Play Cine				
	Refresh Study List				
	Add to Case Review				
	Contours ON/OFF				
	Zoom to Phase Navigation				
	Fullscreen				
	Preferences				
	View All Images in Multi-View				
	Go to Next/Previous Series				

CONTOURS

DELETE	Delete All		FORWARD	Forward All		EDIT	Smooth	
	Delete All (Slice)			Forward Selected			Round	
	Delete All (Phase)			Select and Jump to Next			Refine	
	Cut Selected		MOVE	Drag			Click-Draw	
	Delete Selected (Slice)			Push			Threshold Contour Definition	
	Delete Selected (Phase)			Reposition All				

©June 2020 - Version 5.12