

Windows Quick Keys

BASICS

Undo		Refresh Study List	
Redo		Add to Case Review	
Delete Selected		Contours ON/OFF	
Copy Selected		Zoom to Phase Navigation	
Copy All		Fullscreen	
Paste		Preferences	
Hide All		View All Images in Multi-View	
Play Cine		Go to Next/Previous Series	/

WINDOW

Default	
Auto (Type 1)	
Auto (Type 2)	
Auto (Type 3)	
Auto (Min Max)	

Contours

DELETE

Delete All	
Delete All (Slice)	
Delete All (Phase)	
Cut Selected	
Delete Selected (Slice)	
Delete Selected (Phase)	

FORWARD

Forward All	
Forward Selected	
Select and Jump to Next	

MOVE

Drag	
Push	
Reposition All	

EDIT

Smooth	
Round	
Refine	
Click-Draw	
Threshold Contour Definition	

Windows and the Windows logo are registered trademarks of the Microsoft corporation in the United States and/or any other country.
Quick Keys Valid for cvi42 v5.12 & cvi42 v5.13